



DIY SLANT BOARD




MATERIALS

- (1) Coroplast sheet (corrugated plastic) 18" w x 24" L
- (2) Corrugated plastic cutters
- (3) 2 Hanging rails 3" each
- (4) Measuring tape or ruler
- (5) 6 Velcro strips 3" each (4 hook, 2 loop)
- (6) Double sided tape
- (7) Felt pads

1. Cut along the three black lines on the board with the corrugated plastic cutters.
2. Place a strip of the hook Velcro (not the fuzzy side) on either side of the bottom of the board located in the smallest section that you cut.
3. Directly above the top cut line 4 1/2 inches from the sides, use the double-sided tape to attach the clips that will hold the paper (wide opening towards the top).
4. Add a piece of felt (so it won't slip!) on the top corners of the second section. This will be the bottom of your slant board.
5. Turn your whole board over. Stick a hook Velcro piece 5 1/2 inches from the bottom on either side.
6. Affix two loop pieces of Velcro 17" from the bottom of the board on each side. This will allow you to fold your board for storage!



Flip your board over!



6. affix a piece of loop Velcro 17" from the bottom on either side- now your board can stay closed for storage!

5. stick a piece of hook Velcro 5 ½ inches from the bottom on either side.